




Measuring Guide

Window Blinds

1. Use **Steel Measuring Tape**.
2. Please Measure in **inches**
3. First **Measure Width** (From left to right Side)
4. Then **Measure Height** (From Top to bottom)
5. Decide Your Installation Either **Inside or Above Window**



Measure For Inside Window


Check Window Depth



Minimum depth required 2.50 Inches

Inside Width

Inside Height




Measure inside window width either from window top or center

Measure Inside window height from (top to bottom)

Don't make any deductions. We will deduct for proper functioning

Measure For Above Window



Add 4 inches' extra from both corners of width

Add 4 inches' extra from both corners of height

For example

Window Actual Size 4 x 4

Installation	Width	Height	Area (Sqft)
Inside Window	47.75	48	16
Above Window	56	56	21.77
Window actual Size	48	48	16

To calculate Price

Area Sqft x Blinds Price = Cost per Window + Installation